

**TY PRUS**

---

**668-TYB033**  
10-15 TY PRUS W/  
SUNROOF

ASSY : 87103-47041



FRONT BLOWER ASSY

**CV CAMRO**

---

**668-CVB030**  
10-14 CV CAMRO  
BLOWER ASSY

ASSY : 22762719



FRONT BLOWER ASSY